


Digital Circuits
Prof. Santanu Chattopadhyay
Department of Electronics and Electrical Communication Engineering
Indian Institute of Technology, Kharagpur

Lecture - 61
8085 Microprocessor
(Contd.)

So, whenever we are trying to interface an I O device. So, these are the requirements.

(Refer Slide Time: 00:18)



Basic Concepts in Serial I/O

- Interfacing requirements:
 - Identify the device through a port number.
 - Memory-mapped.
 - Peripheral-mapped.
 - Enable the device using the Read and Write control signals.
 - Read for an input device.
 - Write for an output device.
 - Only one data line is used to transfer the information instead of the entire data bus.


S
S
S

IIT KHARAGPUR | NPTEL ONLINE CERTIFICATION COURSES

So, we have to identify the device through a port number. So, device should have an address and that address has to be generated either in a memory mapped fashion or an I O mapped fashion. So, whatever be the strategy. So, we have to somehow select that particular device and enable the device using the read and write control signals.

So, if you are trying to make some input operation, then the read signal has to be given if you are trying to do some output operation then the write signal has to be given. So, read for input device and write for output device and only one data line is used to transfer the information instead of the entire data bus. So, this serial I O; so, if you are doing a serial I O, then instead of doing that is a 8 bit data transfer. So, we are doing only 1 bit data transfer and that we will see that the RIM and SIM instruction. So, they will be useful for this purpose.

(Refer Slide Time: 01:11)




Basic Concepts in Serial I/O

- Controlling the transfer of data:
 - Microprocessor control.
 - Unconditional, polling, status check, etc.
 - Device control.
 - Interrupt.

IIT KHARAGPUR | NPTEL ONLINE CERTIFICATION COURSES | 164

So, next so, this data transfer that we are talking about. So, this is this is microprocessor control, it can be microprocessor control to the unconditional. So it may be that it is just microprocessor just transfer something to the I O device or read something from the I O device or it may be a polling that is at periodic intervals. So, it transfer some data or it may be some checking some status, etcetera or it may be controlled by the device. So, device may give an interrupts as I said that it is interrupt driven I O. So, device gives an interrupt to the processor telling that some data can be transferred now.

(Refer Slide Time: 01:51)



Synchronous Data Transmission


- The transmitter and receiver are synchronized.
 - A sequence of synchronization signals is sent before the communication begins.
- Usually used for high speed transmission.
 - More than 20 K bits/sec.
- Message based.
 - Synchronization occurs at the beginning of a long message.

IIT KHARAGPUR | NPTEL ONLINE CERTIFICATION COURSES | 165

Now, in case of synchronous data transmission the transmitter and receiver; so they are synchronized with each other a sequence of synchronization signals is sent before the communication begins by which this the communication will be synchronized. So, they will be transferring at some clock rate. So, both side there is transmitter and receiver they should operate at the same clock rate for getting the values properly.

So, there is a synchronization signal usually used for high speed transmission. So, more than 20 kilo bits per second and it is a message based transmission synchronization occurs at the beginning of a long message. So, once it is synchronized, then only the actual transmission of data can start.

(Refer Slide Time: 02:29)



Asynchronous Data Transmission

- Transmission occurs at any time.
- Character based.
 - Each character is sent separately.
- Generally used for low speed transmission.
 - Less the 20 K bits/sec.

IIT KHARAGPUR | NPTEL ONLINE CERTIFICATION COURSES

On the other hand, this asynchronous data transmission; so, a transmission can occur at any time. So, that way it is better. So, you do not have that synchronization sequence to be done and it is character based. So, every character is sent separately. So, there is a particular format for sending the characters and those characters will be having some those characters will be having some start bit stop bit sort of thing. And then, based on that the individual characters will be sent and generally they are used for low speed data transmission; so, less than 20 kilo bits per second.

(Refer Slide Time: 03:04)

Asynchronous Data Transmission

- Follows agreed upon standards:
 - The line is normally at logic one (mark).
 - Logic 0 is known as space.
 - The transmission begins with a start bit (low).
 - Then the seven or eight bits representing the character are transmitted.
 - The transmission is concluded with one or two stop bits.

The diagram shows a timing sequence for one character. It starts with a high level (mark), followed by a low level (start bit), then eight data bits labeled D₀ through D₇, and finally one or two high levels (stop bits). A horizontal arrow labeled 'Time' indicates the progression of the signal. A bracket below the data bits is labeled 'One Character'.


IIT KHARAGPUR | NPTEL ONLINE CERTIFICATION COURSES | 167

So, in case of asynchronous data transmission it follows agreed upon standard. So, there are some there is some standard for asynchronous data transmission. So, both the transmitter and receiver they must agree on the standard that it will follow in terminology in case that the logic 0 is now called the space ok; that is the transmission and a logic one is called mark.

So, this is very old terminology. So, that is followed. So, logic one is called mark and logic 0 is called space and transmission begins with a start bit which is low. So, normally the line is high and when the transmission starts it sends a low start bit and then 7 or 8 bits representing the character is transmitted. So, that is for ASCII 7 bit you know and some other code like e B c D I c that is 8 bit there is extended ASCII which is again 8 bit.

So, anyway; so, that 7 bit or 8 bit will be transmitted. So, that is D 0 to D 7, those bits are transmitted and the transmission is concluded with 1 or 2 stop bits. So, after that 2 1 or 2 stop bits are transmitted after 7 bits after 7 or 8 bits have been transmitted as per the protocol. So, 1 or 2 stop bits will be sent to tell that this is this particular character transmission is done.

(Refer Slide Time: 04:29)



The slide is titled "Simplex and Duplex Transmission" and lists three types of transmission:

- Simplex.
 - One-way transmission.
 - Only one wire is needed to connect the two devices
 - Like communication from computer to a printer.
- Half-Duplex.
 - Two-way transmission but one way at a time.
 - One wire is sufficient.
- Full-Duplex.
 - Data flows both ways at the same time.
 - Two wires are needed.
 - Like transmission between two computers.

The slide also features logos for IIT KHARAGPUR and NPTEL ONLINE CERTIFICATION COURSES, and a small video inset of a man in a yellow shirt speaking.


Now as per as the transmission policy is concerned it can be a simplex transmission. So, only one way transmission; so, the transmission is always from the master device to the slave device like if you are thinking of a system where microprocessor is connected to a number of devices and all these devices maybe output device. And then the processor always transfers to the to the device on the other hand if the input device, then the device processor always reads from the input. So, that way it is like a simplex transmission one way transmission.

So, only one wire is needed to connect the two devices because it is only one way transfer. So, communication from computer to a printer; so, in most of the cases this is a simplex excepting the situation that sometimes printers status has to be told and that comes as a message from the printer. So, for those types excepting those type of cases. So, it is the simplex communication.

Then we have got half duplex communication. So, 2 way transmission, but only one way at a time; so, it is a communication between transmitter and receiver, but at one the sender and the receiver about at one point of time the transmission is in only one direction. So, basically the telephone conversation. So, they are of half duplex nature. So, again one wire is sufficient because at one point of time the communication is going only in one direction, but the problem with simplex and half duplex is that the speed of transmission is low because we cannot communicate both way simultaneously.

So, the full duplex is a situation where the data can flow in both the ways at the same time. So, two wires are needed. So, like transmission between two computers. So, they transmit between themselves simultaneously. So, that is the full duplex type of communication.

(Refer Slide Time: 06:23)



The slide is titled "Rate of Transmission" and contains the following content:


- For parallel transmission, all of the bits are sent at once.
- For serial transmission, the bits are sent one at a time.
 - Therefore, there needs to be agreement on how “long” each bit stays on the line.
- The rate of transmission is usually measured in bits/second or baud.

The slide footer includes the IIT Kharagpur logo, the NPTEL logo, and the text "NPTEL ONLINE CERTIFICATION COURSES". A small video inset of a man in a yellow shirt is visible in the bottom right corner of the slide.

As per as the rate of transmission is concerned for parallel transmission all of the bits are sent at once, because this parallelly all the 8 or 10 bits can go, but for serial transmission the bits are sent one at a time. So, one bit at a time.


So therefore, there needs to be an agreement on how long each bits stays on the line. So, before starting the transmission the sender and receiver they must agree about the bit duration the duration for which the bit should be lying on to on to the line. So, that is; so how long it should be there in the line the rate of transmission is usually measured in bits per second also known as baud. So, which is actually symbols per second baud is actually symbols per second, but many a times, we just use it for the sake of simplicity the bits per second also, but baud is actually symbols per second.



(Refer Slide Time: 07:18)



Length of Each Bit


- Given a certain baud rate, how long should each bit last?
 - Baud = bits / second.
 - Seconds / bits = 1 /baud.
 - At 1200 baud, a bit lasts $1/1200 = 0.83$ m Sec.



 IIT KHARAGPUR |  NPTEL ONLINE CERTIFICATION COURSES


Now how can you determine length of length of each bit given a certain baud rate how long should is bit lasts. So, that is the baud rate. So, if I take baud rate B as bits per second and second per. So, if I just divide other way seconds per bits equal to 1 upon baud. So, at 1200 baud ok; so, a bit will last 1 by 1200 that is 0.83 millisecond; so, each bit from the start of communication from every bit will be 0.83 millisecond. So, that is how the bit durations a bit duration is determined.



(Refer Slide Time: 07:56)



Transmitting a Character

- To send the character A over a serial communication line at a baud rate of 56.6 K:
 - ASCII for A is 41H = 01000001.
 - Must add a start bit and two stop bits:
 - 11 01000001 0
 - Each bit should last $1/56.6K = 17.66$ μ Sec. **Known as bit time.**
 - Set up a delay loop for 17.66 μ Sec and set the transmission line to the different bits for the duration of the loop.




 IIT KHARAGPUR |  NPTEL ONLINE CERTIFICATION COURSES

Now, for transmitting a character; so, now, to send the character over a serial communication line at a baud rate of 56.6 kilo bit per second as a baud rate of 56.6 kilo. So, the ASCII for A is 41 hex that is the; this is the bit pattern ok. So, we must add one start bit and two stop bits. So, this is the start bit ok. So, that is also first we start transmitting from the LSB side; so, first the start bit will go, then the 7 bit 8 8 bits will go and then finally, 2 stop bits.

Now, each bit should be 1 by 56.6 K that is 17.66 microsecond. So, this is also known as the bit time. So, after transmitting a character we should wait for 17.66 microsecond and then only we should transfer the next bit. So, we have to set up a delay loop of 17.66 microsecond and set the transmission line to the different bits for the duration of the loop. So, that has to be done.

(Refer Slide Time: 08:59)



The slide is titled "Error Checking" and contains the following text:

- Various types of errors may occur during transmission.
 - To allow checking for these errors, additional information is transmitted with the data.
- Error checking techniques:
 - Parity Checking.
 - Checksum.
- These techniques are for error checking not correction.
 - They only indicate that an error has occurred.
 - They do not indicate where or what the correct information is

The slide also features logos for IIT KHARAGPUR and NPTEL ONLINE CERTIFICATION COURSES, and a small video inset of a man in a yellow shirt.

So, this program can be written very easily. So, we can do some serial transmission and then wait on a loop for 17.66 microsecond and then transmit the next character next bit.

Now, in the process some error may creep in like say it is transmitted over a signal line. So, that signal line may get some error. So, that how to catch a how to get rid off those errors; so, we have we have to at least check for the error and we need to, if you need to correct it some additional information has to be transmitted for the correction at least for checking also it has to be transmitted.

Now, for error checking techniques; so, there are well known techniques like parity checking and checksum. So, these techniques are for error checking and not for correction they just check whether the received bit pattern that it has got. So, whether it is possibly correct or not and then if there is an error then in many cases. So, it can detect that situation that an error has occurred and it can tell the transmitter that there was a problem with the last transmission so that the transmission can, may be repeated by the transmitter.

However any such error checking technique, it cannot guarantee that all possible errors will be caught at the same time, it cannot indicate whether the wire or what the correct information is ok. So, what is the error or what is the correct information. So, that it cannot check, but it cannot tell, but many a times it can detect the situation that an error has occurred in the transmission.

(Refer Slide Time: 10:39)

Parity Checking

Make the number of 1's in the data Odd or Even.


- Given that ASCII is a 7-bit code, bit D the parity information.
- Even Parity
 - The transmitter counts the number of ones in the data. If there is an odd number of 1's, bit D is set to 1 to make the total number of 1's even.
 - The receiver calculates the parity of the received message, it should match bit D .
 - If it doesn't match, there was an error in the transmission.

So, as per as the parity checking is concerned. So, maybe while transmitting the data bit. So, we make the number of ones in the data odd or even. So, if the ASCII is 7 bit code. So, bit D of the parity information.

So, if the ASCII code is a 7 bit code. So, we can have a one another bit can be added for the parity information for the even parity the transmitter will count the number of ones in the data, if there is an odd number, then this D bit will be set to 1 and make the total number of 1 is even and the receiver will now calculate the now the parity by of the

received message and it should match the bit D ok. So, if it does not match; that means, there was some error in the transmission.

(Refer Slide Time: 11:29)



Checksum

Used when larger blocks of data are being transmitted.

The transmitter adds all of the bytes in the message without carries. It then calculates the 2's complement of the result and send that as the last byte.

The receiver adds all of the bytes in the message including the last byte. The result should be 0.

IIT KHARAGPUR | NPTEL ONLINE CERTIFICATION COURSES | 174


So, that is how this parity checking works other possibility is using checksum. So, parity works at the individual character level because it otherwise what will happen is that it will not have that much capability to determine all the errors ok so that way because if there are so, more than one bit failure. So, this parity bits check may fail ok. So, that may say that the data is the data has been received correctly where as there are multiple failures for which it is not detected by that mechanism.

So, if you have got larger block of data then this checksum is useful. So, the transmitter adds all of the bytes in the message without carries and then calculates the twos complement of the result and send that as the last byte. So, suppose a transmission is a spanning over say 100 bytes what the transmitter will do it will just go and adding those 100 bytes and then at the end it will take A. So, that carries will be discarded and at the end it will calculate the twos complement of the result and the result will be sent as the last byte.

So, at the receiving end; so, it will again calculate all the sum out all the all the messages including the last byte and since I have taken the twos complement there. So, if I add this the result should be 0 because that is a negative number. So now, the result should

become 0. So, the receiver can simply check whether the sum of all these bytes received along with the last byte is 0 or not. So, that way this checksum can be used.

(Refer Slide Time: 13:05)



RS 232

A communication standard for connecting computers to printers, modems, etc.

- The most common communication standard.
- Defined in the 1950's.
- It uses voltages between +15 and –15 V.
- Restricted to speeds less than 20 K baud.
- Restricted to distances of less than 50 feet (15 m).

The original standard uses 25 wires to connect the two devices. **However, in reality only three of these wires are needed.**


IIT KHARAGPUR | NPTEL ONLINE CERTIFICATION COURSES | 175

One standard for the communication serial communication is RS 232 communication standard. So, it is a communication standard for connecting computers to printers modem, etcetera.

The most common communication standard is existing till 1950s, since 1950s, it uses voltage levels between plus 15 volt and minus 15 volt. So, minus 15 volt is taken as logic high plus 15 volt is taken as logic low and it is restricted to speeds less than 20 kilo baud. So, the speed is low restricted distance is within 50 feet or 15 meter. So, distance is also restricted the original standard it uses 25 wires to connect the 2 devices. However, in reality only 3 of this wires are needed. So, original standard was 25 wires, but since the distance is not that much.

So, often three wires are sufficient.

(Refer Slide Time: 13:58)



The slide is titled "Software-Controlled Serial Transmission" and lists the following steps:


- The main steps involved in serially transmitting a character are:
 - Transmission line is at logic 1 by default.
 - Transmit a start bit for one complete bit length.
 - Transmit the character as a stream of bits with appropriate delay.
 - Calculate parity and transmit it if needed.
 - Transmit the appropriate number of stop bits.
 - Transmission line returns to logic 1.

The slide also features logos for IIT KHARAGPUR and NPTEL ONLINE CERTIFICATION COURSES, and a small video inset of a presenter in a yellow shirt.

Now, if we are using some microprocessor for transmitting this data serially. So, you can use some software controlled mechanism for this serial transmission. So, what are the main steps involved in this transmission of a character. So, transmission line is at logic one by default. So, that is high. So, first we have to transmit a start bit for one complete bit length. So, for 1 bit length; so, it should transmit a 0 which is the start bit.

Then it will transmit the character as a stream of bits with appropriate delay. So, it will start transmitting the character bits one by one. So, 7 bits will be transmitted then it will calculate the parity and transmit it if needed. So, it will calculate the parity and the parity if it is has to be 0 or 1. So, based on that it will be sent and trans then it will transmit appropriate number of stop bits and then the transmission line should return to logic 1. So, this is the flow of any software routine. So, that will be responsible for doing the serial transmission.


(Refer Slide Time: 15:08)



. So, suppose I have got a microprocessor where in this bit D 0 is actually doing this is having the bit pattern and that is from D 0. So, it is connected to the output port and that is going to the serial output.

Now if we are transmitting this pattern, then first it will be giving the start pulse which is low then this one will go then all these 0s will go, then 1, then 0; so all these bits. So, they will be shifted one by one and they will be transmitted over a from this bit D 0 on to the outside world serially. And finally, two stop bits will be transmitted ok. So, on this line D 0; so, over the time; so, this happens like this first start bit, then this 1 0 0 0, then 1 0, then 2 stop bits. So, that should be the mechanism.

(Refer Slide Time: 15:58)




So, how you should do the serial transmission first we should setup bit counter. So, setup bit counter. So, that is actually setting the for the bit delay. So, how much delay should be there. So, that is determined by this bit counter that depends on the baud rate that we have we are going to process we are going to have in our system. So, it will set up the bit counter and set bit D 0 of A to 0 to generate a start bit then we wait for a bit time.

So, that way that 0 is transmitted over this from this D 0 of the accumulator for that much time then we get the character into the accumulator wait for a bit time rotate a left ok. So, we rotate a left. So, that is basically a shifting and decrement the bit counter. So, so, we just; so, how many bits will be there. So, those bits will be transmitted; so, till it is last bit; so, it will be it will be going on doing this operation and then it will wait for the bit time. So, how much time it has to wait. So, it will wait for that. So, this way it will be going on. So, this bit counter actually is setting how many bits the data will have.

So, there is so many so many times, the bit will be the bits will be transmitted serially and between every 2 bit transmission. So, we are waiting for this bit time which is fixed by the baud rate, then after the last bit has been transmitted. So, here will send the parity bit and send will send the stop bits. So, they are not shown here very clearly because again, there will be bit times between this parity bit and stop bit two stop bits and all. So, they the bit timing information will be there it is not shown here explicitly.

(Refer Slide Time: 17:46)



Software-Controlled Serial Reception


- The main steps involved in serial reception are:
 - Wait for a low to appear on the transmission line.
 - Start bit
 - Read the value of the line over the next 8 bit lengths.
 - The 8 bits of the character.
 - Calculate parity and compare it to bit 8 of the character.
 - Only if parity checking is being used.
 - Verify the reception of the appropriate number of stop bits

IIT KHARAGPUR | NPTEL ONLINE CERTIFICATION COURSES

On the receiving side, the main steps involved in serial reception is that wait for a low to appear on the transmission line. So, transmission line is generally high; so the start when the transmitter starts sending the signal. So, it will be making it low. So, that way it will be it will be making the transmission line low. So, the receiver should wait for the start bit, it should read the value of the line over the next 8 bit length. So, that is the 8 bits characters will be there. So, it will read the 8 bit lines 8 bit values.

Then it will calculate the parity and compare it to the bit 8 of the character to see whether the parity has been received correctly or not only if the parity bit checking is being used, then only this step will be done and verify reception of the appropriate number of stop bits that is 1 stop bit or 2 stop bit that depends on the standard that we have following. So, based on that it will be getting the appropriate number of stop bits it should it should get those bits.


(Refer Slide Time: 18:49)



So, for transmission for the reception; so, it is from the input port. So, this D 7 the bit D 7 is actually getting the input the serial input in case of 80-85 processor.

Now, it should get in this sequence first it should get a start signal. So, previously the line was high when it gets the start signal, it will know that now the serial transmission is going to start then this. So, this 0 1, then 0 0 0 0 1 then; so, this is the parity bit. So, since this is the following an even parity and the bit this byte that we have sent already to ones are there. So, this parity bit is equal to 0 and then it will expect that 2 stop bits will be transmitted. So, all this should come on to the line D 7. So, if there are this received in this sequence; that means, the character has been received correctly over the serial transmission.

(Refer Slide Time: 19:45)



So, the flowchart for the reception process is like this that it will read the input port. So, as long as there is no start bit detected. So, no action; so, it will just go on reading the input port if a start bit has been detected it will wait for half bit time and bit is still low then it will if bit is high; that means, there was a glitch ok. So, that part that has to be ignored.

So, if there is a glitch that bit is not low; that means, there is a glitch. So, it goes back to check the start bit again and if it is bit is still low; that means, it is not a glitch. So, it will start the bit counter it will wait for the bit time. So, how much time it has to wait for a bit; so, it will wait for that much time and then it will read the input port will decrement the counter the last bit is. So, that way it will go on. So, till whatever be the number of bits that it wants to that it expects to receive.

So, based on that this bit counter will as been set; so, it will be decrementing that counter and when all those bits have been received then it will be it will come to the check parity and wait for the stop bit. So, it will again, this part is not written thoroughly. So, this is again waiting for 2 contiguous 1 bits for the stop bit. So, that way this whole operation takes place. So, this is the flow chart for the serial reception part.

(Refer Slide Time: 21:15)

The 8085 Serial I/O Lines

- The 8085 Microprocessor has two serial I/O pins:
 - SOD – Serial Output Data
 - SID – Serial Input Data
- Serial input and output is controlled using the RIM and SIM instructions respectively.

IIT KHARAGPUR | NPTEL ONLINE CERTIFICATION COURSES

So, in case of 80-85 processor. So, it has got 2 serial pins SO serial output data and SID serial input data. So, serial input and output is controlled using the RIM and SIM instructions that we have in 8085.

(Refer Slide Time: 21:33)

SIM and Serial Output

- The figure below shows how SIM uses the accumulator for Serial Output.

Serial Output Data ← SDO SDE XXX R7.5 MSE M7.5 M6.5 M5.5

0 – Disable SOD
1 – Enable SOD

IIT KHARAGPUR | NPTEL ONLINE CERTIFICATION COURSES

So, just we capitulate the SIM is. So, it has got these bits 7. So, this accumulator bit 7 gets. So, whatever be the value there. So, serial data output and this s D e serial data enable; so, if the serial data enable is equal to 1, then whatever is the available in the SDO that is bit number 7 will be put on to the serial output data in the SIM instruction.

(Refer Slide Time: 22:03)

RIM and Serial Input

- Again, the RIM instruction has dual use
 - Reading the current settings of the Interrupt Masks
 - Serial Data Input
- The figure below shows how the RIM instruction uses the Accumulator for Serial Input

7	6	5	4	3	2	1	0
SDI	P7.5	P6.5	P5.5	IE	M7.5	M6.5	M5.5

The diagram shows an 8-bit accumulator with bits 7 through 0. Bit 7 is labeled SDI (Serial Data Input). Bits 6, 5, 4, and 3 are labeled P7.5, P6.5, P5.5, and IE (Interrupt Enable) respectively. Bits 2, 1, and 0 are labeled M7.5, M6.5, and M5.5 (Interrupt Masks) respectively. An arrow points to bit 7.

IIT KHARAGPUR | NPTEL ONLINE CERTIFICATION COURSES

Similarly, we have got for the serial input the RIM instruction. So, RIM instructions. So, here the serial data input that is coming that that pin value will be coming to SID pin. So, that pin value will be coming to bit number 7 of the accumulator which is the serial data input and here of course, there is no nothing like enable and all. So, this are this is the RIM and SIM instruction that we have seen previously for doing this serial output and input.

(Refer Slide Time: 22:33)

Ports?

- Using the SOD and SID pins, the user would not need to bother with setting up input and output ports.
 - The two pins themselves can be considered as the ports.
 - The instructions SIM and RIM are similar to the OUT and IN instructions except that they only deal with the 1-bit SOD and SID ports.

IIT KHARAGPUR | NPTEL ONLINE CERTIFICATION COURSES

So, using this SOD and SID pins the user would not need to bother about setting up input and output ports, because there on the single line output is single line connection is there.

And these 2 pins themselves can be considered as port. So, you can connect it to some other device that support the serial transmission. And then it can go like this the instruction SIM and RIM are similar to the out and in instruction except that they only deal with one bit serial output data and serial input data ports. So, we can think of this SIM and RIM as if they are equivalent to one bit operation.

(Refer Slide Time: 23:11)

Example

- Transmit an ASCII character stored in register B using the SOD line.

SODDATA	MVI	C, 0BH	; Set up counter for 11 bits
	XRA	A	; Clear the Carry flag
NXTBIT	MVI	A, 80H	; Set D7=1
	RAR		; Bring Carry into D7 and set D6 to 1
	SIM		; Output D7 (Start bit)
	CALL	BITTIME	
	STC		; Set Carry to 1
	MOV	A, B	; Place character in A
	RAR		; Shift D0 of the character to the carry Shift 1 into bit D7
	MOV	B, A	; Save the interim result
	DCR	C	; decrement bit counter
	JNZ	NXTBIT	

B = 11010100
 A = 11010100
 11010100 → B
 10000000 → A
 01
 sm

So, this is an example to transmit an ASCII character stored in register B using the SOD line.

So, first we set up like how many bits we want to transfer. So, there is a 8 bit of ASCII data plus we will be transmitting one stop start bit and 2 stop bit. So, total 11 bits we want to transmit. So, in the c register we note down the counter for 11 bit. So, MVI comma 11; so that will have this 11 bits count the count 11 then XRA is. So, it will clear the carry flag and then MVI A comma 8 0 hex. So, that is setting that D 7 equal to 1 and then this RAR. So, this will bring carry to D 7 and set D 6 to 1.

So, this is actually rotate accumulator I. So, they it will rotate right. So, the bit D 7 is since the carry was reset previously. So, by doing this rotate. So, we will get the carry bit coming 0 bit for the carry coming to D 7 and the bit numbers D 7 was set to one

previously. So, that goes to D 6; so, that now the SIM instruction. So, in the SIM instruction if you see in the SIM instruction; so, we have got this s D e pin s D e bit has to be one for transmitting that so, for sending the start bit. So, this SDO it should be 0 and the SDA should be 1.

So, that is exactly what has happened here you see that after doing this. So, this bit D 6 has become equal to 1. So, SDE is equal to 1 and bit D 7 is equal to 0. So, that is why it is transmitting the start bit. So, this SIM will transmit the start bit.

Then we have to wait for the BITTIME; so this call BITTIME. So, this makes this is a delay routine. So, it is not written here explicitly, but you can understand that it will be calling the it will be the delay routine for that half one bit time the now we want to transfer the characters ok. So, STC so that it will set carry to 1 and move A comma B. So, that will place the character in a now we do a rotate right. So, as a result these shift D 0. So, the character to the carry D 0 of the character to the carry; so, D 0 will come to the to the carry bit and one will come to the D 7, then we save this intermediary value intermediary character that that we have in B register then decrement C and JNX next bit. So, next bit will be we are getting again this carry as D 7 as 1 and then it will be doing a SIM.

So, let us take a pattern. So, I think we can we can take a pattern and try to understand that how it is working suppose if the I said that in the B register, I will have the bit pattern to be transmitted suppose I have the bit pattern 1 1 0 1 0 1 0 0. So, this is the bit pattern to be transmitted. So, up to this much from the beginning we have seen that we have transmitted the start bit. So, up to this much is and then what we are doing. So, we are setting the carry bit to 1.

So, this is the carry. So, carry is set to one and move a comma b. So, a register also gets 1 1 0 1 0 1 0 1 0 0 after that there is a shifting rotate accumulator right. So, as a result; so, D 0 will be coming to the carry. So, this carry gets this D 0. So, this 0 comes here and shift 1 bit to 1 into bit D 7. So, this since carry was previously set to 1. So, this one will be coming to D 7. So, this all these things are shifted. So, this 0 goes here one comes here, then 0 1 0 1.

So, this all these bits will be shifted. So, I will get 1 1 0 1 0 1 0 and then this one from the carry. So, it comes here by this rotate right instruction. So, it will be D 0 bit D 0 of

this accumulator will be coming to the carry and this carry which was set to one. So, that will come to the bit DT 7, then this result this intermediary result is saved on to the B register. So, B has got this particular value and then decrement C. So, we have to 1 bit is decremented and jump on not 0 to next bit. So, it will be coming here, then it will be moving A the 8 0 hex. So, this 8 0 is having this A register will have this 8 0 pattern, this is a register and then rotate right.

So, this one will be coming to this position and this carry. So, which was set which was set to which was having the value 0 which is the LSB pattern that we have that LSB will be coming to this position now after that when I am doing a SIM actually this 0 will be transmitted which is nothing, but the LSB of the character. So, this character is now this bit is now transmitted in the next stage.

Since the B register has got this value. So, 1 0 has been already been transmitted next this 0 is there in the B register. So, this 0 will be transmitted which corresponds to the 0 that we have at the next position. So, this way serially the bits will be transmitted one by one through the sod line using this SIM instruction and all.