

**Indian Institute of technology Madras  
Presents**

**NPTEL  
NATIONAL PROGRAMME ON TECHNOLOGY ENHANCED LEARNING**

**Lecture-14**


**Materials Characterization**

**Fundamentals of Scanning Electron Microscopy**

**Dr. S. Sankaran  
Associate Professor  
Department of Metallurgical and Materials Engineering  
IIT Madras  
Email: [ssankaran@iitm.ac.in](mailto:ssankaran@iitm.ac.in)**

Hello everyone welcome to this material characterization course in the last class he just started with the introduction of scanning electron microscopy and we have just reviewed what all the information one can get out of this scanning electron microscopic techniques and what are the salient features are that you can obtain related to micro structural information and then we started looking at the instrumentation details. So we will continue in that session so this is what I was just showing yesterday.

(Refer Slide Time: 01:02)



The schematic shows the cross sectional view of a SEM and I just started describing this each part so you have this electron gun and then you have series of electron lenses and then so something called scanning points and then you have this magnification control and the scan generator and then you have final lens sub culture and this is where your specimen is kept in the specimen chamber which is maintained at a vacuum of  $10^{-4}$  Pascal I just mentioned yesterday and then you have this detector system and then you have the control console.

So what it what we have to understand from this a schematic the electron gun just generates the electron and accelerates to 0.12 Or 3 electron volt and then the electron are passing through this electron lenses are scan coils and then the primary function of this section is to de magnify this probe diameter because typically if you take a tungsten hairpin the probe diameter is not sharp enough to obtain the micro structural details however this scan coils or electron lenses d magnify that probe to a very small size in the order of 10 nanometers when it finally reaches on the specimen surface.

So this is a primary function of this coils and electron lenses and if you look at the right hand side schematic which shows the specific action of this scan coils what you see here is the high-


energy electron beam which is accelerated by the electron then comes through this scan coils and you see that the electron beam is deflected of the optic axis in a discrete locations in a line you can see that and then finally the second coil is also deflects and again on a disk discrete location in a second line.

So like that it will go on depending upon the number of line coils you have in the column and what you have to understand is before it reached the beam reaches the final aperture at a pivot point it has been deflected of the optic axis by the first coil and then the beam is brought back to this optic axis by the second coil and it crosses the final aperture and this action this deflecting off and on the optic axis of the electron beam occur still it makes the rectangular raster on the specimen surface that is scanning action here.

So this happens so finally the magnification of the image is the ratio between the specimen region on which the electron beam is probing and the in the CRT screen where the raster is going from the one end to the other, so we will look at that ratio and understand the magnification just since we are talking about the restring here I just want to mention the magnification related to the specimen region where the probe is scanning this area and the CRT screen what you are looking at the area of this here T screen.

And what you are seeing is also a  $w$  is a working distance we will discuss about it is again a very important one of the parameters to for the operator control in the scanning electron microscopy.

(Refer Slide Time: 06:21)




So now we look at the other schematic where it also describes the what kind of detecting system is employed in this scanning electron microscopy and you see here this electron beam strikes the specimen and you have some interaction volume shown here and from there you get typical signals secondary electrons as well as back scattered electrons like we discussed yesterday. And you see that these signals are collected by the detectors okay the image is formed by I mean the electronic system converts the signal point by point and form an image.

So you see that the signals are collected by this detectors we will look at the detector details little later just to give a kind of an idea to understand how ACM works let us assume that this is an detector which can detect these two signals and you see the details if you have the positive potential or positive voltage then it can accept secondary electrons as well as backscattered electrons.

But when you apply a negative voltage it can only accept backscattered electrons and not the secondary electrons this is because your secondary electrons have a lower energy which will get repelled by this field then the signals are collected by the scintillator or the photo multiplying multiplier tube and which is getting further amplified with an amplifier and finally it reaches the

CRT where you see the image of your specimen of interest. So this gives you a kind of overall a function of how the SEM works I hope you got some rough idea by looking at all these three schematics.

(Refer Slide Time: 09:09)




**Scanning Electron Microscopy (SEM)**  
***(Physical Basis)***

- A source of electrons is focused (in vacuum) into a fine probe that is rastered over the surface of the specimen.
- As the electrons penetrate the surface, a number of interactions occur that can result in the emission of electrons or photons from (or through) the surface.
- A **reasonable fraction of the electrons** emitted can be collected by appropriate detectors, and the output can be used to modulate the brightness of a **cathode ray tube (CRT)** whose x- and y-inputs are driven **in synchronism with the x-y voltages rastering the electron beam.**

NPTEL  
Department of Materials Characterization, Institute of Materials, The Chinese University of Hong Kong, Shatin, New Territories, Kowloon, Hong Kong, China

What now we will do is we will sum summarize whatever we have just discussed in the form of few sentences. So that you can just verify this again and again a source of electron is focused in a vacuum define probe that is Rusted both surface of the specimen as the electron penetrate the surface a number of interactions occurs that can result in the emission of electrons or photons from the surface a reasonable fraction of the electrons emitted can be collected by the appropriate detectors and the output can be used to modulate the brightness of a cathode ray tube whose X&Y inputs are driven in synchronism with the XY voltage restring the electron beam.

(Refer Slide Time: 10:07)




The slide is titled "SEM- Instrumentation" in white text on a blue background. It contains three bullet points in white text. The first bullet point states: "The beam is defocused by a series of magnetic lenses. Each lens has an associated defining aperture that **limits the divergence of the electron beam.**" The second bullet point states: "By increasing the current through the condenser lens, the focal length is decreased and the divergence increases. **The lens therefore passes less beam current on to the next lens in the chain.**" The third bullet point states: "Smaller spot sizes, often given higher dial numbers to correspond with **the higher lens currents** required for better resolution, are attained with a smaller signal-to-noise ratio." At the bottom left of the slide is the NPTEL logo, and at the bottom right is the number "11".

So if you look at the description of the magnetic lenses the beam is defocused by series of magnetic lenses are the each lens has an Associated defining aperture that limits the divergence of the electron beam so what I just want to go back and show these are the apertures we talk about each lens has got some kind of aperture which decides the divergence of the electron beam by increasing that current through the condenser lenses the focal length is decreased and the divergence increases the lens therefore passes less beam current on to the next lens in the chain.


Remember the smaller the spot sizes often given higher dial numbers to the numbers to correspond with the higher lens currents required for the better resolution are attained with a smaller signal-to-noise ratio this is very common practice in an SEM as well as TEM probably I will show you when we go to that appropriate lab and look at the actual equipment and the controls you can see that all small smaller spot size often given higher dial numbers.

(Refer Slide Time: 11:46)

A blue slide titled "SEM- Instrumentation" with three bullet points. The slide includes the NPTEL logo and text at the bottom left.

SEM- Instrumentation

- The beam next arrives at the final lens-aperture combination. The final lens does the ultimate focusing of the beam onto the surface of the sample.
- The sample is attached to a specimen stage that provides x and y motion, as well as tilt with respect to the beam axis and rotation about an axis normal to the specimen's surface.
- A final "z" motion allows for adjustment of the distance between the final lens and the sample's surface. This distance is called **the working distance**.

 NPTEL  
National Programme on Technology Enhanced Learning  
© 2009 NPTEL. All rights reserved. For more information, visit [www.nptel.ac.in](http://www.nptel.ac.in)


The beam next arrives at the final lens aperture combination the final lens does the ultimate focusing of the beam onto the surface of the sample the sample is attached to a specimen stage that provides X&Y motion as well as the tilt with respect to the beam axis and rotation about an axis normal to this specimen surface your final is that motion that is vertical motion allows for the adjustment of the distance between the final length and the sample surface this distance is called the working distance I just mentioned in the schematic. So the working distance is the distance between the final lens and this sample surface.







(Refer Slide Time: 15:43)



**Scanning Electron Microscopy (SEM)**

**What kinds of samples can be examined?**


- Sample requirements are more stringent.
- They must be vacuum compatible
- Must be either conducting or coated with a thin conducting layer.
- A variety of contrast mechanisms exist in addition to the topological, enabling the production of maps distinguishing high- and low-Z elements, defects, magnetic domains, and even electrically charged regions in semiconductors.

**NPTEL**  
National Programme on Technology Enhanced Learning  
© 2008 NPTEL. All rights reserved. For more information, visit [www.nptel.ac.in](http://www.nptel.ac.in)

So now what kind of samples can be examined the sample requirements are more stringent they must be vacuum compatible they must be either conducting or coated with a thin conducting layer, and we will look at the details of the sample preparation and its requirements little later we will see it but just give you an kind of introductory remark you should realize that the material should be vacuum compatible and it should be either conducting or we have to quote a thin conducting layer on the specimen.

A variety of contrast mechanisms exist in addition to the topological enabling the production of maps distinguishing high and low atomic number elements defects magnetic domains and then even electrically charged regions in semiconductors since this also we discussed yesterday different kinds of mechanisms are possible.

(Refer Slide Time: 17:07)

A blue rectangular slide with white text. The title "Scanning Electron Microscopy (SEM)" is centered at the top in a white, sans-serif font. Below the title are three bullet points, each starting with a white dot. The second bullet point contains two lines of text that are underlined in yellow. At the bottom left of the slide is the NPTEL logo, which consists of a circular emblem with a globe and the letters "NPTEL" below it. At the bottom center, there is a small line of white text: "© Copyright of NPTEL is characterized by surface interaction. The Film © Richard Goodwin et al. Daresbury Laboratory, Oxford, UK".

Scanning Electron Microscopy (SEM)


- They are produced by different mechanisms.
- When a high-energy primary electron interacts with an atom, it undergoes either inelastic scattering with atomic electrons or elastic scattering with the atomic nucleus.
- In an inelastic collision with an electron, some amount of energy is transferred to the other electron. If the energy transfer is very small, the emitted electron will probably not have enough energy to exit the surface.

NPTEL  
© Copyright of NPTEL is characterized by surface interaction. The Film © Richard Goodwin et al. Daresbury Laboratory, Oxford, UK

When a high energy primary electron interacts with an atom it undergoes either inelastic scattering with atomic electrons or electric scattering with the atomic nucleus in an inelastic collision with an electron some amount of energy is transferred to the other electron if the energy transfer is very small the emitted electron will probably not have enough energy to exit the surface.

So we are now getting into the details of electron beam and under interaction with the specimen you will see.

(Refer Slide Time: 18:04)



The slide features a dark blue background with white text. At the top, the title "Scanning Electron Microscopy (SEM)" is underlined. Below the title, there are two bullet points. The first bullet point states that when the energy of the emitted electron is less than about 50 eV, it is referred to as a secondary electron (SE). The second bullet point states that most of the emitted secondaries are produced within the first few nm of the surface. In the bottom left corner, there is a circular logo with a globe and the text "NPTEL" below it. At the very bottom, there is a small line of text: "© Copyright of NPTEL. Characterization, Surface Analysis: The Film of Richard Johnson et al., University of London, U.K." and a small number "15" in the bottom right corner.

### Scanning Electron Microscopy (SEM)


- When the energy of the emitted electron is less than about 50 eV, by convention it is referred to as a secondary electron (SE),
- Most of the emitted secondaries are produced within the first few nm of the surface

**NPTEL**  
© Copyright of NPTEL. Characterization, Surface Analysis: The Film of Richard Johnson et al., University of London, U.K.

15


When the energy of the emitted electron is less than about 50 electron volt by convention it is referred to as a secondary electron yesterday I just mentioned that the classification of this signals something like secondary electron and backscattered electrons is based upon its varying energies, so you have the effects number here when the emitted electron is less than about 50 electron volt it is referred as secondary electron. Most of the emitted secondary are produced within the first few nanometers of the surface.

(Refer Slide Time: 18:52)



Scanning Electron Microscopy (SEM)


- Backscattered electrons (BSEs) are considered to be the **electrons that exit the specimen with an energy greater than 50 eV**, including Auger electrons.
- The higher the atomic number of a material, the more likely it is that backscattering will occur.
- Thus as a beam passes from a low-Z (atomic number) to a high-Z area, the signal due to backscattering, and consequently the image brightness, will increase.
- There is a built in contrast caused by elemental differences.

 NPTEL  
National Programme on Technology Enhanced Learning  
© Copyright of Materials Characterization, Surface Interface, Thin Films, Coatings and Nanotechnology - University, Boston, USA

Backscattered electrons are considered to be the electrons that exit the specimen with an energy greater than 50 electron volt including low Z electrons the higher the atomic number of the material the more likely it is that backscattering will occur thus a beam as a beam passes from a low atomic number to a high atomic number area the signal due to back scattering and that consequently the image brightness will increase there is a built in contrast caused by the elemental differences.


So you have to understand that the atomic number of the element increases the scattering event also increases and eventually you get image brightness as well we will look at this kind of electron beam and its interaction and its volume everything we will look at them in later and this is just and I am introducing how the signals are classified and what kind of interaction they will make with the specimen.

(Refer Slide Time: 20:27)



Scanning Electron Microscopy (SEM)


- One further breaks down the secondary electron contributions into three groups: SEI, SEII and SEIII.
- SEIs result from the interaction of the incident beam with the sample at the point of entry.
- SEIIs are produced by BSEs on exiting the sample.

  
NPTEL  
The National Institute of Technology, Chandigarh, Punjab, India. For more information, visit [www.nptel.ac.in](http://www.nptel.ac.in)

One further breaks down the secondary electron contribution into three groups second electron one secondary electron to and second electron three secondary electron once result from the interaction of the incident beam with the sample at the point of entry secondary electron tubes are produced by backscattered electrons on exiting the sample.



(Refer Slide Time: 22:11)



Now we will just go to the scanning electron microscopy imaging modes what are the kinds of imaging mode we employ while we carry out the microstructure investigation using scanning electron microscopy you see this schematic this is the electron beam you have some notation called DPI P alpha P and V not for major electron beam parameters are defined where the electron probe impinges on the specimen what are those four parameters electron probe diameter that is DP beam size electron probe current IP electron probe convergence  $\alpha P$  there is a typo here alpha P and electron beam accelerating voltage  $V_0$ .

Please remember all this beam parameters will have a specific effect on the image quality and the information which you get as well as on the resolution that is why we specifically talked about these parameters we will look at the effect of each one of these beam parameters on the micro structural details which you obtain as well as on the resolution we will see one by one.



(Refer Slide Time: 24:01)




The effect of probe size and the probe current on the resolution and the and the high current mode so you have a three micrographs of some surface the voltage employed is 20 kilo volt the magnification for these two would sorry this is not magnification is something wrong here the magnification is about 10,000 x for all these three you have DP of 50 nanometers I p of 1 equal peers and you see that schematic I mean.

So this micrograph be is obtained with the DP dot of 20 nanometers and an IP in order of 55 Pico amperes and the third micrograph is obtained with the DP of 130 nanometers and IP of 320 PA. So what do you see it is not that you have a specific combination of all these parameters is well defined you see that as the probe diameter increases you are not seeing the a clear resolution here the resolution is not improved at the same time if you increase the probe current also the solution is not improved but at this particular combination of DP and IP you have a better result compared to this first one and third one. So you see that you have a combination of a probe diameter and the probe current gives a better resolution.

(Refer Slide Time: 26:22)

SEM imaging Modes and Operation

- Effect of convergence angle on depth of focus mode



$\alpha_p = 15 \text{ mrad}$        $\alpha_p = 1 \text{ mrad}$


Voltage: 20 kV, Marker = 11.8  $\mu\text{m}$ , Varying aperture size

A loss of background features occurs as the convergence angle increases

**NPTEL**  
National Programme on Technology Enhanced Learning


And next we look at the effect of convergent angle on the depth of focus you see the image taken in the same region here the  $\alpha$  P that is convergent angle is 15 mille radians and here it is one mil rhenium the voltage is 20 kilo volt and this marker is 11.6microns and you have the varying aperture size you see that a loss of background features occurs as the converging angle increases. So if you want if you look at this image the background is not details are not clear however you can see that much more details are seen which is I in behind this region. So you have the convention angle effect as well on the resolution of the micrograph.

(Refer Slide Time: 27:38)



Now if you look at the effect of accelerating voltage in a low voltage mode the micrographs taken here with five LOL kva and 15 kv are 30 kv and you see that the surface detail of a surface oxide growth on a copper is same with the different voltage you would clearly appreciate that the increasing the acceleration voltage not necessarily help there a solution you see only at the lower accelerating voltage you are able to look at the details of you are able to see the details of the oxide layer on the specimen the low-k be imaged shows greater surface detail the high cave image shows loss of information about the surface oxide due to the be penetration.

(Refer Slide Time: 28:56)



So now we will see what are all the operator control in ACM to obtain a better resolution or a control we will see that the animation which is showing the kind of aperture size effect we will see and let me first describe this schematic and then we will see what is that we try to understand from the schematic so this is an electron gun then again the beam comes through the condenser lenses and then final aperture and then again goes to the next stage and the objective lens and then you see finally it reaches the example.


What we are trying to say here is when you obtain optimal aperture angle that minimizes the abrasions on the final probe size that means we need to understand what is this optimum aperture angle by looking at the image quality we are relatively it is free from this abrasions you judge this the final convergent angle controls the image depth of focus the aperture determines the current in the final pro because only a fraction of the current spread out to the angle alpha one passes in the aperture angle alpha finally.

So what we are trying to say here is you see that the beam is spreading to the angle of  $\alpha$  one quite large and only fraction of this is going to enter the final aperture and which has the aperture angle controlled by this objective lenses or aperture the aperture bloom stones into lanes controls

the final angle from the large spread out angle in the previous lenses, so that is what we are trying to understand here.

So that aperture an operator can control and then decide whether this particular settings will be useful in obtaining the information with minimal aberrations.

(Refer Slide Time: 32:18)




Now you will look at the effect of working distance again you see these two animations of the ray diagram and you see that the distance between the final aperture and the sample surface is working distance like me to defined in the previous one, so you have this to schematic displaying the ray diagram with two different working distance this is  $w_1$  and this  $w_2$  and then the schematic nicely displays increasing the working distance how you are were converging the ray converging positions are this I mean displayed here or how they are different with the adjustment of the working distance.

The increase in working distance produces a large spot size at the specimen so you can see that here it is small spot and here it is a large spot and the degradation of the image resolution obviously that is going to cause some resolution decrease from the solution converging angle

decreases and improve depth of focus and the convergent angle which we have already discussed and smaller the convergent angle the improved lay depth of focus that we have seen already weakening the objective to focus operation to the links.

So you increase the working distance this also will happen and which also increases this current length and reduces the magnification so working distance if you play around these are all the points which have to keep in mind and the operator should again judge by looking at the working distance and the image quality he obtains and then decide what gives him the best.

(Refer Slide Time: 34:25)



Now we will look at the effect of condenser lens strength here is the schematic again you can see that the effect of condenser lens strength on the final probe diameter the increase in the condenser lens strength increase the  $D$  magnification of the each lens and reduces the probe size the final probe size can only be reduced at the expense of decreasing the probe current and a conscious choice between minimizing the probe size or maximizing the probe current.

So either you if you want to reduce the final probe size either you play with the minimum probe size or maximum probe current that you have to take a call by looking at the again Lee kind of

information you are interested in and also kind of resolution you want obtained at particular magnification.

So you can clearly see that from the schematic depending upon the condenser lens current so you see that how the final probe diameter which is falling on the sample is reduced to a very small probe here, so having talked about this probe diameter we will go through some of the important aspects to be noted we are always interested in minimum probe size if he in order to resolve very smaller details and if you recall in the beginning of this second part of the course where we talked about fundamentals of electron optics we also discussed about a quite a bit of quite a bit of information on the lens aberrations in the case of electromagnetic lenses and its optical systems where we discussed that all the aberrations are going to contribute little bit to the final probe diameter on the electron beam. So this is what we are now worried summarizing here.

(Refer Slide Time: 38:11)

**Probe Diameter**

**Minimum probe size**

- Calculations of the probe size assume that  $d_p$  is quadrature sum of the diameters of Gaussian and other aberration disks

$$d_p = \left[ d_g^2 + d_c^2 + d_z^2 + d_s^2 \right]^{1/2}$$

- At normal voltages of 10-30 kV the relationship between probe size and probe current can be calculated at  $\alpha_{opt}$

$$d_{min} = KC_c^{1/2} \lambda^{1/2} \left( \frac{i_p}{\beta C_c^2} + 1 \right)^{1/2}$$

- **Maximum probe current at 10-30 kV** Measure of resolution 1

$$i_{opt} = \frac{3\pi^2}{16} \beta \frac{d^2}{C_c^2}$$

NPTEL  
National Institute of Technology, Manipal  
National Institute of Technology, Karnataka  
Manipal, India

The calculations of the probe size assume that DP is quadrature some of the diameters of Gaussian and other aberration disks. So the final diameter is DP is equal to  $d_g$  square plus  $d_c$  square plus  $d_z$  square plus  $d_s$  square to the power of at normal voltages of 10 to 30 kv the relationship between probe size and probe current can be calculated at  $\alpha$  optimum  $d$  minimum is

equal to  $k c s$  to the power  $1/4$  times  $\lambda$  to the power  $3/4$  into  $I_p$  by  $\beta m \lambda$  square plus  $1$  whole to the power  $3/8$  and the maximum probe current at  $10$  to  $30$  kilo volt has got an expression. Similar to this  $I_{max}$  equal to  $3 \pi^2$  by  $16$  into  $\beta$  into  $D_p$  to the power  $8/3$  divided by  $C s$  to the power  $2/3$ .

(Refer Slide Time: 39:44)

Gaussian Probe Diameter

- To fully understand how probe size varies with probe current, we need to calculate the minimum probe size and the maximum probe current
- The aberration-free Gaussian probe diameter  $d_G$ , which is the full-width at half-maximum height (FWHM) of the intensity distribution of  $d_G$

$$d_G = \sqrt{\frac{4I_p}{\beta \pi^2 \alpha_p^2}}$$

• The current in the final probe can be estimated as

3


And we also look at what is this Gaussian probe diameter to fully understand how probe size varies with the probe current we need to calculate the minimum probe size on the maximum probe current the abrasion free Gaussian probe diameter  $d_g$  which is the full width at half maximum height of the intensity distribution of  $D_G$  where  $D_{G^2}$  equal to square root of for  $I_p$  divided by  $\beta \pi^2 \alpha_p^2$  the current in the final probe can be estimated as  $I_p$  is equal to square root of  $\beta \pi^2 \alpha_p^2 D_G^2 / 4$ .

So all these expressions will give you a kind of an idea the important four parameters which we talked about how they are related basically with respect to the probe diameter please understand that is you should not confuse this probe diameter with the electron beam size so electron beam along the column is not called probe diameter the probe diameter is a final probe electron beam which exit from the final aperture and next to immediately to the specimen surface.



So that is called probe diameters do not confuse this parameter with the electron beam size along the rest of the column and then you see that that probe diameter has got the dependence on all the other parameters and that is what these mathematical expressions relate that is all I want you to appreciate.


(Refer Slide Time: 41:50)



Gaussian Probe Diameter

$$i_p = \sqrt{\frac{\beta \pi^2 \alpha_p^2 d_G^2}{4}}$$

- If there were no aberrations in the system, it would only be necessary to increase the convergence angle to increase the probe current at a constant probe diameter

 NPTEL

If there were no aberrations in the system it would only be necessary to increase the convergence angle to increase the probe current at the constant probe diameter. So I would like to stop this lecture here and then we will continue on the various aspects of the SEM operations and a little bit of theory of contrast mechanisms and how this equipment can be exploited can be exploited in order to obtain more micro structural details we will continue in the next class. Thank you.

**IIT Madras Production**

Funded by

Department of Higher Education

Ministry of Human Resource Development

Government of India

[www.nptel.ac.in](http://www.nptel.ac.in)

Copyrights Reserved